

Add-on Starter Relay Installation Instructions

Start Your Engine!
LarryB's
WWW.fostertruck.com

1. Disconnect the positive side of battery.
2. Connect the black ground wire from the relay to a suitable ground. (make sure connection is tight).

3. Locate a good mounting spot for the relay. In my case I used the common body ground screw located beside the battery. You can use any mounting location that is close.

4. On the starter you will notice a spade connector with a single small wire attached. Your connection may be a different type. Disconnect this wire and replace with the blue wire from the relay.

5. The original starter wire you removed now needs to be attached to the white wire from the relay. You may need to use different connector depending on your vehicle.

6. You are now ready to attach your positive lead to your battery. Also you will need to attach the red wire to the positive battery lead or clamp.

7. You're now ready to get in, turn the key and bring your beast to life. You will notice that the starter spins faster and there is no more clicking.

8. If you experience any difficulties during your installation please feel free to e-mail me at larrybuckinc@gmail.com

